



NEXT! BACKLIT

Set-up Instructions



Backlit SEG Fabric Pop-Up System






1. Set-up frame



2. Lock the center hubs



3. Hang channel bars on the perimeter of the frame



Prairie

DISPLAY / CHICAGO, INC.


www.prairiedisplay.com

758 INDUSTRIAL DRIVE
ELMHURST, IL 60126
630-834-8773

NEXT! BACKLIT

Backlit SEG Fabric Pop-Up System


Channel bar removal




CORRECT



INCORRECT



CORRECT



INCORRECT

Remove channel bars evenly
to avoid possible damage

Prairie

DISPLAY / CHICAGO, INC.

758 Industrial Drive • Elmhurst, IL • 630-834-8773 • www.prairiedisplay.com

Install front graphic



4. Install front graphic, start with endcaps




5. Move to center of frame then to corners.

NEXT! BACKLIT

Backlit SEG Fabric Pop-Up System

Install lights and back graphic



6. Hang lights (Bulb side facing back of display, not front)



See light kit wiring diagram



7. Install back graphic



8. Finish by plugging in

Prairie

DISPLAY / CHICAGO, INC.

758 Industrial Drive • Elmhurst, IL • 630-834-8773 • www.prairiedisplay.com

NEXT! BACKLIT

Backlit SEG Fabric Pop-Up System


Installation of optional leveling foot



Prairie

DISPLAY / CHICAGO, INC.

758 Industrial Drive • Elmhurst, IL • 630-834-8773 • www.prairiedisplay.com



1. Connect fluorescent lights 1-22 to each other and add hanger bracket clips and light braces.
2. Add pigtail cord connections and single power cord.
3. Hang fluorescent lights (bulb side facing back of display, not front) from the cross points of each top frame scissor.