



Lift the 1-piece stand by the pole and shake to pop each leg (attached by bungee cord) into a socket. Your Summit will now stand on its own.



Carefully unroll your graphic. The top of the graphic is in the center of the roll. Attach the hardware at the top of the graphic to the top of the Summit unit mast.



Raise the mast and graphic together until your graphic hangs straight. Tighten the twist lock.

Summit



Hook the loop, attached to the bottom of the graphic, onto the pin on the base.



Adjust the unit mast to improve the graphic tension if necessary.

